

# INSTRUCTION MANUAL

## Installation Notice

1. Floor drain should be installed on the site.
2. The shower should be installed only after the completion of house interior decoration.
3. Clean pipes to get rid of mud, sand or other debris blocked in pipes before installation.
4. Check whether the threads can be matched. Otherwise, installing forcefully will damage the components.
5. After installation, check all the joints to make sure they are firmly connected. Then keep water flowing. Turn on and off repeatedly to ensure no leaking problem. After that, the product is ready for normal use.
6. Hand the manual to users.

## Operation Notice


1. The product is used under water temperature 4~70°C, water pressure 0.05~0.5 MPa.
2. Do not hang heavy things on the product.
3. Remember to turn off the water if no water comes out of it (especially when nobody in the house or during the decoration period).
4. Clean the surface of the product regularly to keep it bright. Note: Please do not use inappropriate tools such as sharp brushes, rough sponges, scouring pads or corrosive detergent. And it is not recommend to use the detergent sold in the market, because its formula changes frequently. Please clean the product with wet cloth and soapy water after usage. Then rinse the soap off with clean water and dry with a soft cotton cloth.
6. Adjust the temperature before use (Do not turn the hand shower towards human body) to avoid scald.
7. Do not disassemble the product without help from the professionals.

## Installation Steps

1. Connect the hand shower with the shower hose, tighten the nut.
2. Run the water to check whether the product is well installed.

## Cleaning

If water sprays unevenly or some of nozzles do not spray, it usually results from blockage of nozzles. Remove the hand shower, clean the nozzles with a brush and vinegar, then wash the hand shower with clean water. After cleaning, install it back and run the water.



\* The installation diagram is only for reference, the product is subject to the real object.